



ECO Spot LED10™ User Manual

Thank you for choosing an ECO Spot LED10™ Gobo projector. This unit is equipped with a fan cooled 10W LED bulb with 50,000hrs bulb life. No more need for replacement bulbs.

Please read this manual before installing or operating this fixture, follow the safety precautions listed below and observe all warnings.



WARNING! Select the correct Line Voltage with the selector on the back of the unit before Operating.

Package Contents

- ✓ Projector with power cord
- ✓ Test Gobo
- ✓ Spare gobo retaining ring and Spare drive belt

Safety Information

- Place your fixture at a suitable place with good air flow.
- Keep flammable materials away from the fixture.
- Minimum distance to flammable material = 1 ft (0.3m).
- Minimum distance to illuminated surface = 3.3 ft (1.0m).
- Provide a minimum clearance of 4 in (10cm) around air vents.
- Use only genuine spare parts for part replacement.
- Do not look directly into the lamp; it can result in eye damage.
- Don't touch the hot surface during operation, use gloves if necessary.
- Always unplug the unit from the power mains before any service is done.
- Allow 20 minutes to cool down before servicing the unit.
- Replace Lamps only with the same type, other lamps may cause damage.
- Light fixtures should be installed and maintained only by qualified personnel with experience in lighting equipment and general electrical experience.

Electrical Safety

- Disconnect the fixture from AC power before handling the fixture.
- Always ground (earth) the fixture electrically.
- Use only a power source that complies with local building and electrical codes and has both, overload and ground-fault protection.
- Do not use the fixture if the power cable or power plug is in any way damaged, defective or wet, or if they show signs of overheating.



Handling Instructions

- Before the initial start-up, please unpack and carefully check for damage caused during transportation.
- Place your fixture at a suitable place with good air flow.
- Make sure there are no flammable materials close to the lamp.
- When suspending the fixture above ground level, verify that the structure can hold at least 10 times the weight of all installed devices.
- Verify that all external covers and rigging hardware are securely fastened and use an approved means of secondary attachment such as a safety cable.

Warranty

One Year from Date of Purchase. For warranty, contact your dealer or Globus New Media LLC at 1-800-213-1092 or 1-831-431-8800

Focusing

- Power up the projector by pressing the larger switch in the back.
- Turn on the gobo rotator with the smaller switch in the back and switch it off when the gobo projects in the desired position.
- Focus the projection by twisting the lens in and out until the image is well focused. When used for the first time, the lens will often need to be twisted outwards many rotations to reach the focusing point.

Gobo Rotator

- The gobo rotator can be turned on/off with the small switch on the back plate.
- There are no controls for rotating speed or direction.

Multi-functional Yoke

- The yoke can slide over the whole length of the fixture body to accommodate multiple pointing directions.
- The yoke acts as a stand foot.
- The yoke can be screwed to a wall or ceiling or fastened with a C-clamp



Gobo Replacement

- Unplug the power cord.
- Unscrew the four thumbscrews to remove the front cover with the projection lens.
- Push the two pins of the gobo retaining ring together and pull out the retaining ring. Carefully remove the old gobo and replace it with the new gobo.
- If you have a glass gobo, place the more reflective side towards the light bulb.
- Replace the retaining ring and make sure it evenly pushes the gobo all the way back.
- Replace the front cover and adjust the focus.



